

Date	29 october 2024
Inspector	Simon Clavan
Email	edumas@plannord.com
Dealer	Plannord
Make	Douvan
Model	DX350LC-5K
Model Year	2019
Hours	6166
Serial Number	DWGCCEBJJ1020280

DEVELON



General/Cosmetic

	New	Good	Fair	Poor	Repair	Notes	Repair \$
1. Body/Metal/Fiberglass	☐	☐	☐	☐	☒		
2. Cab Glass	☐	☐	☐	☐	☒		
3. Cab Mirrors	☐	☐	☐	☐	☒		
4. Worklights/Covers	☐	☐	☐	☐	☐		
5. Steps/Ladders/Handrails	☐	☐	☐	☐	☒		
6. Paint	☐	☐	☐	☒	☐		
7. Hood	☐	☐	☐	☒	☐		
8. Grill	☐	☒	☐	☐	☐		
9. Fenders	☐	☐	☐	☐	☒		

Cab/Control System - Key On

	New	Good	Fair	Poor	Repair	Notes	Repair \$
10. Seat/Armrests	☐	☐	☐	☒	☐		
11. Seat Belt	☐	☐	☒	☐	☐		
12. Air Conditioner/Heater	☐	☐	☐	☐	☒		
13. Control Screen/Panel	☐	☒	☐	☐	☐		
14. Gauges	☐	☒	☐	☐	☐		
15. Battery	☐	☒	☐	☐	☐		
16. Travel Alarm	☐	☐	☐	☐	☐	n/a	
17. Swing Alarm	☐	☐	☐	☐	☐	n/a	
18. Engine Warning Lights	☒	Yes		☐	No		
19. Interior Lights Function	☐	☒	☐	☐	☐		
20. Oil Pressure	☐	☒	☐	☐	☐		
21. Control Pattern Change Operational	☒	Yes		☐	No		
22. Disconnect Controls	☐	☐	☐	☐	☐	n/a	
23. Steering Controls	☐	☐	☐	☐	☐	n/a	
24. Brake Control	☐	☐	☐	☐	☐	n/a	
25. Powertrain Controls	☐	☐	☐	☐	☐	n/a	
26. Horn	☐	☒	☐	☐	☐		
27. Backup Alarm	☐	☒	☐	☐	☐		
28. Rearview Camera	☐	☒	☐	☐	☐		
29. Hydraulic Controls	☐	☐	☐	☐	☒		
30. Steering Wheel	☐	☐	☐	☐	☐	n/a	
31. Wiper Blades and Motor	☐	☐	☒	☐	☐		
32. Turn Signals	☐	☐	☐	☐	☐	n/a	

Engine

	New	Good	Fair	Poor	Repair	Notes	Repair \$
33. Prior to Start Oil Fluid Level Test	☐	☒	☐	☐	☐		
34. Engine Oil Color	☐	☒	☐	☐	☐		
35. Type of Engine	☒ DEVELON	☐ Perkins	☐ Scania	☐ Isuzu			
36. Engine Model	☐	☐	☐	☐	☐	DL08	
37. Emission Control Label/EPA Compliance	☐ ITF			☒ T4F			
38. Blowby at Idle	☐	☐	☒	☐	☐		
39. Starter	☐	☒	☐	☐	☐		
40. Turbo or Blower	☐	☐	☐	☒	☐		
41. Injector Pump	☐	☐	☒	☐	☐		
42. Exhaust System	☐	☒	☐	☐	☐		
43. Radiator Hose	☐	☐	☒	☐	☐		
44. Oil Leaks	☒ Yes			☐ No			
45. Fuel Tank	☐	☒	☐	☐	☐		
46. DEF (Diesel Exhaust Fluid) Quality (If Applicable)	☐	☒	☐	☐	☐		
47. Fuel Leaks	☐ Yes			☒ No			
48. Coolant Quality	☐	☐	☐	☐	☒	Couleur Brun	
49. Coolant Level	☐	☐	☐	☐	☒	manque 20 litres	
50. Coolant System Leaks	☒ Yes			☐ No		Fuite coin Pompe à Eau	

Drivetrain/Powertrain

	New	Good	Fair	Poor	Repair	Notes	Repair \$
51. Transmission Type							
52. Transmission Condition	☐	☐	☐	☐	☐	N/A	
53. Torque Converter	☐	☐	☐	☐	☐	N/A	
54. Linkage	☐	☐	☐	☐	☐	N/A	
55. Final Drives	☐	☐	☐	☐	☒		
56. Front Axle	☐	☐	☐	☐	☐	N/A	
57. Front Axle Oscillating Pin Wear	☐	☐	☐	☐	☐	N/A	
58. Rear Axle	☐	☐	☐	☐	☐	N/A	
59. Rear Axle Oscillating Pin Wear	☐	☐	☐	☐	☐	N/A	

Hydraulics

	New	Good	Fair	Poor	Repair	Notes	Repair \$
60. Pumps	☐	☐	☒	☐	☐		
61. Valves	☐	☒	☐	☐	☐		
62. Hydraulic Tank	☐	☒	☐	☐	☐		
63. Hose	☐	☐	☐	☐	☒		
64. Aux Hydraulic Plumbing	☐	☐	☐	☐	☒		
65. Loader Lift Cylinder	☐	☐	☐	☐	☐	N/A	
66. Bucket Tilt Cylinder	☐	☐	☐	☐	☒		
67. Boom Swing Cylinder	☐	☐	☐	☐	☐	N/A	
68. Boom Lift Cylinder	☐	☒	☐	☐	☐		
69. Stick/Dipper/Arm Cylinders	☐	☐	☐	☐	☒		
70. Auto Greaser Function Properly	☐ Yes			☐ No			
71. Safety Lever Function Properly	☒ Yes			☒ No			

Frame/Linkage

	New	Good	Fair	Poor	Repair	Notes	Repair \$
72. Frame Condition	☐	☐	☐	☐	☒		
73. Lift Arm Condition	☐	☐	☐	☐	☐	n/a	
74. Tilt Cylinder/Pins/Bushings	☐	☐	☐	☐	☐	n/a	
75. Coupler to Arm Pins	☐	☐	☐	☐	☒		
76. Steering/Cylinder	☐	☐	☐	☐	☐	n/a	
77. Pin/Bushings Stick to Coupler	☐	☐	☐	☐	☒		
78. Pin/Bushings Boom to Stick	☐	☐	☒	☐	☐		
79. Pin/Bushings Boom Base	☐	☒	☐	☐	☐		
80. Stick Condition	☐	☐	☐	☐	☒		
81. Boom Condition	☐	☒	☐	☐	☐		

Undercarriage/Mobility

	New	Good	Fair	Poor	Repair	Notes	Repair \$
82. Tire Type							
83. Tire Condition	☐	☐	☐	☐	☐	n/a	
84. Tire Tread Condition	☐ 75%	☐ 50%	☐ 40%	☐ 30%		n/a	
85. Wheel Condition	☐	☐	☐	☐	☐	n/a	
86. All Wheel Studs/Nuts/Lugs Secure	☐ Yes			☐ No		n/a	
87. Track Type	☐ Rubber			☒ Steel			
88. Track Shoe Width (mm)			800 mm				
89. Grouser Height			30 mm				
90. Link Height % Remaining	☐ 75%	☐ 50%	☒ 40%	☐ 30%			
91. Pad Width			38 mm				
92. Rollers % Remaining	☐ 75%	☐ 50%	☐ 40%	☒ 30%			
93. Sprockets % Remaining	☐ 75%	☐ 50%	☒ 40%	☐ 30%			
94. Idlers % Remaining	☐ 75%	☐ 50%	☐ 40%	☒ 30%			
95. Brake Lines and Hoses	☐	☐	☐	☐	☐	n/a	
96. Park Brake/ Emergency Brake	☐	☐	☐	☐	☐	n/a	

Attachment

	New	Good	Fair	Poor	Repair	Notes	Repair \$
97. Coupler Condition	☐	☐	☐	☐	☐	manquant	
98. Coupler Type						AHE - W2851	
99. Coupler Make						Kingshooter	
100. Bucket Condition	☐	☐	☐	☒	☐		
101. Bucket Type						franchise	
102. Bucket Make						PJB	
103. Bucket Size						54 Paces	
104. Bucket Edge Condition	☐	☐	☐	☒	☐	2.85 verge	
105. Additional Safety Features						GTS - W285G	
106. Non-Standard Options							
107. Additional Attachment Information	☐	☐	☐	☐	☐	Thumb	

Limited Function Check – Machine On						New	Good	Fair	Poor	Repair	Notes	Repair \$	
108.	Neutral Idle to Rev – RPM Check												
109.	Neutral Rev to Idle					☐	☐	☐	☐	☐			
110.	Drive Forward					☐	☒	☐	☐	☐			
111.	Drive Backward					☐	☒	☐	☐	☐			
112.	Simple Work Function					☐	☒	☐	☐	☐			
113.	Accelerator (Drive) Pedal					☐	☒	☐	☐	☐			
114.	Arm/Stick Out					☐	☒	☐	☐	☐			
115.	Arm/Stick In					☐	☒	☐	☐	☐			
116.	Loader Boom Up/Loader Boom Down					☐	☒	☐	☐	☐			
117.	Bucket/Attachment Function					☐	☒	☐	☐	☐			
118.	Swing					☐	☒	☐	☐	☐			
119.	Exhaust Smoke Level Normal					☒ Yes				☐ No			
120.	Engine Smoke Present					☐ Yes				☒ No			
121.	Hydraulic Fluid Present on Ground					☒ Yes				☐ No			
If yes, where?													

Shipping Dimensions		Dimensions	Notes	Repair \$
122.	Operating Weight			
123.	Overall Length			
124.	Overall Width			
125.	Overall Height			